


Parts Catalog

Model: AHU018145WESNCXF454B

Exploded View




18

18.1

18.2

18.3



Spare Parts

Item #	Spare Parts Code	Part Name (EN)
1	12223000002377	Chassis Assembly
1.1	12223000002363	Chassis components
1.2	12223000006387	Support Bar
2	12223000010536	Side Panel Assembly
3	12223000010529	Evaporator Connecting Plate Assembly
4	12223000002181	Support Bar Assembly
6	12223000017737	Side panel assembly
7	12223000002126	Air Duct Assembly
7.1	12223000002333	Wind wheel fixed plate
7.2	12223000001960	Air duct damper
7.3	12223000002111	Blockoff Plate
7.4	12223000001965	Duct under the baffle
8	12123000001080	Drain Pan Assembly

Item #	Spare Parts Code	Part Name (EN)
8.1	15500402000023	Seal Plug
9	12223000002118	Drain Pan
10	15823000007264	Evaporator assembly
10.1	15823000004347	Evaporator
10.2	12223000005759	Evaporator Baffler
10.3	15223000000125	Evaporator output pipe assembly
10.4	15223000000127	Distributary ass'y
10.5	15423000005998	Expansion valve ass'y
10.5.1	15500213002750	thermostatic expansion valve
10.6	12100901000010	Seal Ring
11	12223000010535	Evaporator Connecting Plate Assembly
12	12223000010527	Evaporator Connecting Plate Assembly
13	12200101000021	Wind Turbine Parts
14	11002015020032	Brushless DC Motor
15	12223000001992	Motor Holder
16	12223000001934	Motor Holder Assembly
17	11201708000008	Terminal
18	17223000010922	E-part box ass'y
18.1	12223000014910	Electrical Installation plate
18.2	17123000012025	Indoor unit main control board
18.3	11203103002859	Linear Transformer
19	17223000010923	Refrigerant Sensor
19.1	12223000017718	Fixing board
19.2	11201003000424	Gas sensor