

Parts Catalog

Model: SHP0182301152SNCXFC454B


Exploded View


18.1

18.2

18.3

18.4





Spare Parts

Item #	Spare Parts Code	Part Name (EN)
1	12223000A03809	Side board ass
1	12223000A03814	Side board ass
2	12223000A08845	Supporting board
3	12200104000008	Fan
4	11301805000012	Motor Mounting bolt
5	11002015020573	Brushless DC Motor
6	12123000000464	Motor installation board ass'y
7	12923000A00171	Grille
8	11301002000001	Stainless steel bolts
9	12223000A08851	Top cover assembly
10	15823000004421	Condenser ass'y
11	15423000006065	Throttle assembly

Item #	Spare Parts Code	Part Name (EN)
12	15423000003178	Stop valve ass'y
13	15423000006086	Suction pipe ass'y
13.1	15427000007112	Fusible plug assembly
13.2	17400516001308	Pressure switch
14	15423000006068	4-way valve ass'y
14.1	15123000010875	Pipe joint ass'y
14.2	15423000006074	4-way valve assembly
14.2.1	15500216002964	4-way valve ass'y
14.2.2	17400516001309	Pressure switch
15	15500508000080	Accumulator cylinder
16	12223000A08840	Base assembly
17	11102010002104	Fixed speed scroll compressor
18	17223000A09218	E-part box assembly
18.1	12223000A08850	Installation plate of electric parts subassembly
18.2	17123000A04385	Outdoor main control board assembly
18.3	17400103000146	Capacitor
18.4	11203502000032	AC contactor
19	12223000A08836	Side panel assembly
20	12223000A08847	Side panel assembly
21	17400513006835	Discharge Temperature switch
22	11201007003446	Room Temperature Sensor
23	11201007005723	Pipe Temperature Sensor
24	17402001000040	Compressor electric heater